








## Quickstart Guide

Please see the User Manual for more detailed instructions

<p>1</p>  <p>OR</p>	<p>2 <u>Insert into Base</u></p> 	<p>3 <u>Switch On</u></p> 	<p>4 <u>Settings</u></p>  <p>Set to medium volume</p> <p>Set threshold to 7</p> <p>☀ = Extra-bright mode for outdoor use</p>
<p>5 <u>Screening</u></p>  <p><b>Detection</b></p> <p><b>No Detection/Ready</b></p> <p>6" / 15cm</p> <p>7' / 2m</p> <p><u>TIP</u> Decrease sensitivity or relocate unit if red flashes regularly when no one is being screened.</p>		<p>6 <u>Charging</u></p>  <p>OR</p>  <p>Charge 4 hour</p>	